

Defender Series Case with Kickstand


1

Start by removing the kickstand from the case by sliding it to one side until it releases.




2

Peel away and remove the outer slipcover from the shell.



3

Separate the shell halves by locating the arrows and releasing each snap along all four sides.




4

Place your device into the bottom half of the shell.



5

Place the shell top on the device and snap the two case pieces together along all edges.




6

Align the openings on the back of the slipcover with the notches on the back of the bottom half of the shell and wrap the slipcover around the shell.



7

Press around all edges to ensure slipcover is engaged in all grooves and notches for a secure fit.



8

Align the straight end of the kickstand with the bottom of the case. Place the kickstand in the slots and slide to the side to reattach.

Note: if the pencil loop becomes detached during the installation process, simply snap it back into place before putting on the slipcover.

